



Available Spares :

The spare parts available are shown in heavy outline Parts drawn in broken line are not supplied as spares.



Available Spares

Capsule & Seat Assembly set (State capsule filling - F Fill or D Fill)	A
Strainer screen & Gasket Kit	B, C

How to Order :

Always order spares by using the description given above and stating the size and type of steam Trap. For Codes Ref. User Manual.

Example : 1 Capsule & Seat assembly set for 15 NB BPT 21 Steam Trap F fill.



[www.forbesmarshall.com](http://www.forbesmarshall.com)

**Spirax Marshall Pvt. Ltd.**

P B # 29, Mumbai Pune Road, Kasarwadi, Pune 411 034. India.  
Tel.: 91(0)20 - 27145595 / 39858555 Fax: 91(0)20 - 27147413

Call +91-9225637451...Your helpline for Everything in Steam

**Domestic Operations:**

Ahmedabad, Alibag, Bangalore, Bhopal / Indore, Chandigarh, Chennai, Coimbatore, Delhi, Hyderabad, Jamshedpur, Kolkata  
Mumbai, Nagpur, Navi Mumbai, Surat, Trichy, Vadodara & Visakhapatnam

**International Operations:**

Bangladesh, Canada, Egypt, Indonesia, Iran, Kenya, Malaysia, Nepal, Sri Lanka, Thailand, U.A.E. (Instrumentation)  
(Boilers & Boiler accessories), USA

 **Forbes  
Marshall**  
Trusted Partners.  
Innovative Solutions.